

# fumapem® F-14100

#### General

Membrane type: Fluorinated cation-exchange membrane – non-reinforced – thickness 100  $\mu$ m, with low resistance, high mechanical stability, low dimensional swelling, and high stability in acidic environment.

Application: Various electrochemical application such as Fuel Cells or Redox-Flow Batteries etc.

Membranes are identified by membrane type and identification number (Lot Number). Please refer to this type and identification number in case of queries.

## **Delivery**

The membrane is the nearly colorless, transparent foil, delivered in between paper layers. Carefully separate the membrane from the paper layers.

### **Handling**

Keep membrane package closed / sealed when unused. Unpack membrane only for direct use and process it immediately after opening. Store, handle and process the membrane in a clean and dust-free area. Use only new and sharp knives or blades, when cutting the membrane.

Always wear protective gloves when handling the membrane. Handle with care, be sure not to puncture, crease or scratch the membrane, otherwise leaks will occur. All surfaces which may get into contact with the membrane during inspection, storage, pretreatment and mounting must be free of sharp edges or angles.

#### **Pretreatment**

The membrane does not need any pretreatment and is ready for use. Please assemble the membrane in dry form.

If you have any concerns about storage, chemical stability, pretreatment or before proceeding, please feel free to contact us for further information.



## Physical and chemical data of fumapem® F-14100

fumapem®	unit	F-14100
membrane type		cation exchange membrane
appearance		transparent, colorless
backing foil		none
reinforcement		none
counter ion		H⁺ form
delivery form		dry
thickness (dry)	μm	92 - 105
IEC (ion exchange capacity)	meq g <sup>-1</sup>	0.56 – 0.84
area resistance in H <sub>2</sub> O at T = 25 °C in H-form <sup>a)</sup>	$\Omega$ cm $^2$	< 0.25
conductivity in H <sub>2</sub> O at T = 25 °C in H-form <sup>a)</sup>	mS cm <sup>-1</sup>	> 50
selectivity 0.1 / 0.5 mol/kg KCl at T = 25 °C b)	%	> 97
uptake in H <sub>2</sub> O at T = 25 °C in H-form °)	wt %	< 16
dimensional swelling in H <sub>2</sub> O at T = 25 °C in H-form <sup>d)</sup>	%	< 9
Young's modulus at 23 °C / 50 % r.h. e)	MPa	> 350
tensile strength at 23 °C / 50 % r.h. e)	MPa	> 13
elongation at break at 23 °C / 50 % r.h. d)	%	> 250
Version <sup>f)</sup>	2.1	Valid from August 20th 2020

- a) measured in two-electrode cell (through-plane), sample activated in 10 % H<sub>2</sub>SO<sub>4</sub>, T = 80 °C, 24 hrs before measurement
- b) determined from membrane potential measurement in a concentration cell
- c) reference membrane dried over P<sub>2</sub>O<sub>5</sub> in vacuo, sample activated in 10 % H<sub>2</sub>SO<sub>4</sub>, T = 80 °C, 24 hrs before measurement
- d) reference membrane dried at ambient conditions (25 °C, 50 % r.h.), sample activated in 10 %  $H_2SO_4$ , T=80 °C, 24 hrs before measurement e) determined by stress-strain measurement at T=25 °C and 50 % r.h., according to DIN EN 527-1, sample activated in 10 %  $H_2SO_4$ , T=80 °C, 24 hrs before measurement
- f) Changes without prior notices may apply.

Note: The product is not certified for drinking water applications. The data are not measured directly on the item supplied. The data sheet does not release the customer of the necessity of a goods inwards control procedure. All information included in this data sheet is based on tests and data believed to be reliable. The data do not imply any warranty or performance guarantee. It is the user's responsibility to examine performance, suitability and durability of the product for the intended purpose. FUMATECH BWT GmbH does not assume any liability for patent infringement resulting from the use of this product. Fumapem® is a trademark of company FUMATECH BWT GmbH.

Hereby, it is certified that all results of the measured item comply with the margins of the internal specification defined in the technical datasheet. All measurements and data recording are conducted in accordance with standardized procedures following the ISO 9001 certification.



Tel: +86 13003038751 Fax: +86 553-7458-388 Email: contact@scimaterials.cn www.scimaterials.cn